

### **Installing Custom Profiles in Best RIP 5.0.1**

- 1) Place CD in drive.
- 2) Open Windows Explorer.
- 3) Browse to CD files.
- 4) Copy files on CD.
- 5) Open “Best RIP” folder.
- 6) Open “Color Proof” folder.
- 7) Open “ICC Profiles” folder.
- 8) Open “Epson 9600” folder.
- 9) Paste files that were copied from the CD to this folder.
- 10) Open Best RIP software.
- 11) Click on “Settings.”
- 12) Select “Profiles and Linearizations.”
- 13) Make sure that a check mark is placed in “Look for new profile on restart” box.
- 14) Click on “Find new linearization now” button.
- 15) Economy Scrim Water Resistant Matte Banner, PolyCotton Blend Gloss Canvas and PSA Water resistant Matte Vinyl medias have Profile Keepers already built and can now be used immediately through Best RIP.
- 16) Premium Gloss Photo Paper, Premium Satin Photo Paper and Valéron® Water Resistant Matte Banner need a Profile Keeper built prior to using them (follow instructions in next section).

### **Creating Profile Keepers in Best RIP 5.0.1**

- 1) Open Best RIP software.
- 2) In the “Hold Queue” search for the copied .BPL file of desired media.
- 3) After the .BPL file is selected a dialog box will open up with the saved settings.
- 4) **MAKE NOTE OF THE “TOTAL INK LIMIT” VALUE.**
- 5) Cancel all of the dialog boxes.
- 6) Open “Best RIP” folder.
- 7) Open “Color Proof” folder.
- 8) Open the “Profile Keeper” file.
- 9) Click on “...” following “Paper Profile”
- 10) Search for the .ICC file within the folders that were copied over from the CD that corresponds to the specific media you are creating a Profile Keeper for.
- 11) After the .ICC file is selected, search for the .BPL file within the same folder.
- 12) Name the new file with a descriptive name for the media that includes “\_PK” in the file name for easier reference later on (follow steps 10-14 in previous section to load new profiles and Profile Keepers).